

The first step to install your frameless glass pool fencing is to mark out the exact location of your fence. Use a pencil or chalk to mark the line where the fence is to be located.



Mark out each piece of glass required, allowing a gap of minimum 10mm between each glass sheet. The glass sheets are supplied with holes for the Stainless steel feet. Mark out the location of each foot (two per panel). Mark out the gate panel allowing a measurement of **920mm** between the side panels for the gate. This measurement is important for the gate to have the required clearance for the hinges and latch.

Frameless glass foot brackets are available in both bolt down style (flang), or drill in style (extended post).



If extended posts are used a hole 75mm in diameter and 100mm deep is required for each post. Holes can be core-drilled using a water cooled diamond bit drill. Coredrills can be rented from equipment rental stores such as Kennards Hire. Use a drill press, (or a piece of plywood with a hole as a guide) to drill your holes accurately and to prevent damage to the pool tiles.

Once all the coreholes have been drilled, assemble the feet brackets to the bottom of the glass panels. Starting at one end, insert and brace the panels one at a time. Use spacers and support blocks to hold the glass and feet in position. Check the level of each panel using a spirit level and string line, make sure all the panels are square and plumb prior to cementing.



Once all panels and gates are inserted and braced the feet can be cemented using an approved epoxy resin such as R180 fibre glass with H180 hardener, available through your local hardware or builders supplies.